





Metal carport OWNER'S MANUAL

Size 12 Ft X 19 Ft



PARTS LIST

Part number	Quantity	Part number	Quantity	Part number	Quantity
A1	1	B6	1	E4	1
A2	1	B7	1	E5	1
A3	1	B8	1	F1	1
A4	1	C1	1	F2	1
A5	1	C2	1	F3	1
A6	1	C3-1	1	F4	1
A7	1	C4-2	1	F5	1
A8	1	C5	1	F6	1
A9	1	D1	1	F7	1
A10	1	D2	1	F8	1
A11	1	D3	1	F9	1
A12	1	D4	1	F10	1
A13-1	1	D5	1	F11	1
A14	1	D6	1	G1	1
B1	1	D7	1	G2	1
B2	1	D8	1	G3	1
B3	1	E1	1	G4	1
B4	1	E2	1	G5	1
B5	1	E3	1	G6	1

PARTS LIST

Part number	Quantity	Part number	Quantity	Part number	Quantity
G7	1	GB2	2	SK	2
G8	1	GB3	6	J1	4
G9	1	GW1	3	GE	2
G10-2	1	GW2	1	KS	1
G11	1	M1	2	H1	8
G12	1	M2	4	X1	4
L1L	2	M3	2	W1	10
L1R	2	M4	4	Gloves	2
L1	2	M5R	1	screwdriver	2
L2	1	M5L	1	specification	1
KL1	1	M6R	1	F1	several
KR1	1	M6L	1	F2	several
KL2	1	M7	4	F3	several
KR2	1	M8	2	F4	several
Q1	28	M9R	1	F5	standby
Q2	4	M9L	1	spare screws,use this screw when other screws can't fit	
Q3	6	M10	2		
Q4	38	M11	2	F6	10
GB1	4	M12	2	F7	several

Warning & Attention:

- Take care of sharp edges; Please wear gloves;
- You are advised to read the whole procedure before installing it;
- Try to assemble this product on the flat ground, otherwise it is difficult to carry out;
- It would be much easier to assemble the product with three or more people;
- All panels are clearly marked and care should be taken to use the correct one. It is important that these instructions are followed step by step;
- Each screw has a surplus quantity, which can be used in reserve;
- After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

Tools:



Gloves



Ladder



Electric drill




Phillips screwdriver



Safety Helmet Hat






goggles




Notice:

As shown in the picture, connect the two adjacent parts and fix them with F1.

2 Position Secure F6 to the ground






Notice:





As shown in the picture, connect the two adjacent parts and fix them with F1.


2 Position Secure F6 to the ground



Notice:

As shown in the picture, connect the two adjacent parts and fix them with F1.







Notice:


As shown in the picture, connect the two adjacent parts and fix them with F1.


2 Position Secure F6 to the ground



Notice:

As shown in the figure, link the two adjacent parts and fix them with F1.






Notice:






As shown in the picture, connect the two adjacent parts and fix them with F1.


2 Position Secure F6 to the ground




Notice:

As shown in the figure, link the two adjacent parts and fix them with F1.









Notice:
Fix the M11 ends to the top with F1 as shown.



Notice:
1 Instructions: As shown in the figure, use F1 to install L1 and L2 to the top.
2 Description: As shown in the picture, use F1 to fix L1 installation to the inner hole.






Notice:

1 Description: Use F3 to connect L1L and L1R.

2 Instructions: Put the connected L1L and L1R into the position of 2 and fix it with F1.

(Insert the connected L1L and L1R under L1, with L1 on top, as shown).






3 Note: Install the connected L1L and L1R in the corresponding positions according to the hole positions, as shown in the figure.




Notice:

As shown in the figure, assemble the wall tiles Q1 and Q3 successively, top, middle and bottom


The tiles on the wall need to be screwed on with F1.







Notice:



As shown in the picture, the steps of door frame and wall tile installation are the same.
Screws are required for the upper, middle and lower parts of KR and KL and are fixed with F1.



Notice:

Install Q4 sequentially, overlapping every 2 pieces, each Q4 needs 3 rows of screws,
1 and 2 positions with F1, 3 positions with F7.





Notice:





As shown in the picture, connect GW1 and GW2 with F1 and fix them to the roof.


Notice:

Step 1: As shown in the picture, fix GB2 and GB3 to the side edge with F1.

Step 2: GW1 (GW2) and GB1 common hole positions, fixed with F1, GE finally fixed with F1,

Step 3: GB1, GB2 and J1 common holes are fixed with F1.





Notice:


As shown in the picture, it is the inside of the door. After placing the parts according to the drawing, Screw F4 through the four corners of the door and screw F3 through the middle of both sides of the window

Instructions: Place M7 and M12 in position 1 and fix them with F4 nuts, as shown in Figure 1.

2 Description: After fixing the nuts of F4, use F1 to fix X1 in the position of 2, as shown in Figure 2.

3 Instructions for use: In the other position, put the other end of M7 and M12 into the nut of F4 to secure.

As shown in Figure 3.





Notice:


As shown in the picture, it is the inside of the door. After placing the parts according to the drawing, Screw F3 through the corners of the door and the middle of both sides

Instructions: Place M7 and M12 in position 1 and fix them with F4 nuts, as shown in Figure 1.

2 Instructions for use: In the other position, put the other end of M7 and M12 into the nut of F4 to secure.

As shown in Figure 2.





Notice:


As shown in the picture, it is the inside of the door. After laying out the parts according to the drawings, Thread the F4 screw through the four corners of the door and F3 through the middle of the two sides

1 Instructions: Place M10 in position 1 and fix it with F4 nut, as shown in Figure 1.

2 Description: After fixing the F3 nut, use F1 to fix X1 in the position of 2, as shown in Figure 2.



3 Instructions for use: In another position, fasten the other end of the M10 into the nut of F4.



As shown in Figure 3.



Notice:


As shown in the picture, use F1 and F2 to fix SK and H1 to the shed.








Notice:

As shown in the picture, use F1 and F2 to fix SK and H1 to the shed.





Instructions 8 pages



Instructions 4 pages

