



Metal Garden Shed

OWNER'S MANUAL

Size 8 Ft X 6 Ft



Tall walk in Shed

Quick & Easy Assembly

Ridge Reinforced walls






Wide Double Doors

Available in Various Sizes

















Take care of sharp edges;

















Please wear gloves;

















It will take 2 people 3-4 hours to install.





PARTS LIST



NO1	PART	QTY
D1L		1
D1R		1
D2L		2
D2R		2
D3L		1
D3R		1
D5		1
S1R		1
S1L		1
S2L		2
S2R		2
S3L		1
S3R		1
N1		1
KL		1
KR		1


NO1	PART	QTY
L1L		2
L1R		2
B1		4
B2L		2
B2R		2
C		2
L3		2
L4L		2
L4R		2
GB1		4
GB2		4
GW1		2
M2		4
M3		4
M4		2
M5L		1

NO1	PART	QTY
M5R		1
Q1		12
Q2		4
Q3		3
Q4		12
M		2
J1		4
MB		2
DJT		4
FJT		4
ZJT		4
DGT		4
GE		2
GD		4
G2		4
F1		

PARTS LIST

NO1	PART	QTY
B3L		1
B3R		1

NO1	PART	QTY
F3		
LSM		

NO1	PART	QTY
F4		

Install LSM at the leaking place after installing the screw.

Warning & Attention:

- Take care of sharp edges; Please wear gloves;
 - You are advised to read the whole procedure before installing it;
 - Try to assemble this product on the flat ground, otherwise it is difficult to carry out;
 - It would be much easier to assemble the product with three or more people;
 - All panels are clearly marked and care should be taken to use the correct one. It is important that these instructions are followed step by step;
- Each screw has a surplus quantity, which can be used in reserve
- After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

Tools:




Gloves



Ladder



Electric drill




Phillips screwdriver



Safety Helmet Hat



goggles




Note: Take care of sharp edges.
All panels are clearly marked and care should be taken to use the bcorrect one. It is important that these instructions are followed step by step.

NO.	PART	Qty.
D1R		1
D1L		1
D2R		2

NO.	PART	Qty.
D2L		2
D3L		1

NO.	PART	Qty.
D3R		1
DJT		4

NO.	PART	Qty.
F1		
DGT		4



Notice:

DJT installation: At the junction of two arrows, please install in the direction indicated by the arrows (→↔).


DGT installation: Two ground pallets are connected to the DGT as shown in the figure.

Each DGT needs to be fixed with two F1s.




The installation space should be flat, and at least 3000x2300mm. The foundation is fixed on the ground in this space.


A




B






 Note: Please wear gloves


NO.	PART	Qty.
D5		1




Notice:
You do not need to install screws in this step. Align the holes, which are the same as in the previous step.











NO.	PART	Qty.
Q2		4
F1		



Notice:
In this step, only the three holes in the middle of Q2 need to be installed and reserved on both sides.
The reserved holes are shared with the following steps.




NO.	PART	Qty.	NO.	PART	Qty.
S1R		1	G2		4
S1L		1	F1		
S3L		1	ZJT		2
S3R		1			










Notice:

G2 has been placed in S1R and S1L before shipment. If it slides out, follow step A to insert it.

S1L and S1R, S3L and S3R, are connected by ZJT and fixed by F1, respectively.



NO.	PART	Qty.	NO.	PART	Qty.	NO.	PART	Qty.
S2L		2	FJT		4	ZJT		2
S2R		2	N1		1	F1		




Notice:


ZJT installation: At the junction of two arrows, please install in the direction indicated by the arrows (→←).


FJT installation: Connect the two-layer frame to the DGT as shown.

Each DGT needs to be fixed with two F1s. S1 has no fixed hole position

N1 mounting: Install the N1 on the connected S1R and S1L, securing it from the bottom up with 2 F1s.



NO.	PART	Qty.
F1		








Notice:

In this step, only the middle three holes need to be installed, and both sides need to be reserved.

The reserved hole is shared with other steps.

The walls are tiled on the outside and framed on the inside





NO.	PART	Qty.
Q1		12
Q3		3
F3		
F1		



Notice:


As shown in the picture, assemble the wall tiles in turn, Q1\Q3, The top, middle and bottom of the wall tiles need to be screwed,

The upper and lower ends are fixed with F1, and the middle is fixed with F3.













NO.	PART	Qty.
Q1		12
Q3		3
F3		
F1		




NO.	PART	Qty.
KL		1
KR		1
F1		
F3		




NO.	PART	Qty.
C		2
F3		
B3R		1
B3L		1




Notice:
Connect C with 2 B1, L1L, L1R, B3L and B3R and fix them with F3;
After completing step A, bend the other end of C about 45° and connect it to the bottom of L3









NO.	PART	Qty.
F1		



Notice:
The assembled roof support parts are successively installed on the wall tiles with F1



NO.	PART	Qty.	NO.	PART	Qty.
L3		2	F3		
L4L		2	F1		
L4R		2			



Notice:



Step A: Insert the connected L4R and L4L into the B2L and B2R holes respectively.


Step B: Connect two L3s and place them on L1R and L1L.

Temporarily fixed with F1, later need to remove the hole and share with Q4.

The other end of part C is fixed to the bottom hole of L3 with F1.



Step C: Connect L4R and L4L and install both sides outwards, as shown in the figure.

NO.	PART	Qty.
Q4		12
F1		




Notice:

Install Q4 in sequence, overlap between every 2 pieces, and each Q4 needs 2 rows of F1 fixed.







NO.	PART	Qty.	NO.	PART	Qty.
GB1		4	F1		
GB2		4	J1		4



Notice:

As shown in the picture, fix GB1 and GB2 with F1 on the edge,
The four corners GB1, GB2, J1 share the hole position.




NO.	PART	Qty.
GW1		2
GE		2
F1		
















Notice:




Put the GW1 on the roof, install it with the GE, and fasten it at both ends with F1.



① Description :GW1, Q4, GB1 share side holes.







NO.	PART	Qty.	NO.	PART	Qty.	NO.	PART	Qty.	NO.	PART	Qty.
M2		4	M5L		1	M		2	F3		
M3		4	M5R		1	GD		4	F4		
M4		2	MB		2	F1					





NO.	PART	Qty.
F1		
F3		
F4		



NO.	PART	Qty.
F1		
F3		
F4		



NO.	PART	Qty.
F1		



Notice:
Use F1 to secure the installed door to the pulley
The adjustment of the door can be achieved by the three holes of the pulley being at different heights

