



Metal Garden Shed

OWNER'S MANUAL

Size 9 Ft X 4 Ft



Tall walk in Shed

Quick & Easy Assembly

Ridge Reinforced walls






Wide Double Doors

Available in Various Sizes

















Take care of sharp edges;

















Please wear gloves;













It will take 2 people 2 - 3 hours to install.





PARTS LIST

NO1	PART	QTY
D1		1
D1L		1
D1R		1
D2		2
D3L		1
D3R		1
S1R		1
S1L		1
S2		2
S3L		1
S3R		1
KL		1
KR		1
L1L		1
L1R		1
L2L		1

NO1	PART	QTY
L2R		1
B1		4
GB1		6
GB2		2
M2		4
M3		4
M4		2
M5L		1
M5R		1
Q1		8
Q2		4
Q3		5
Q4		9
M		4
N1		1
B3L		1

NO1	PART	QTY
B3R		1
J1		4
MB		2
FJT		4
ZJT		1
G2		4
GD		4
F1		264
F3		10
F4		16
F8		7
F11		20

PARTS LIST

NO1	PART	QTY
LSM		60
F14		250

Install LSM at screw exposure, Prevent collisions.

This part is used with all screws, Such as F1 and F3, located in the external tool room Easy to seal and waterproof.

Warning & Attention:

-Take care of sharp edges; Please wear gloves;

-You are advised to read the whole procedure before installing it;

-Try to assemble this product on the flat ground, otherwise it is difficult to carry out;

-It would be much easier to assemble the product with three or more people;

-All panels are clearly marked and care should be taken to use the correct one. It is important that these instructions are followed step by step;

Each screw has a surplus quantity, which can be used in reserve

-After assembly, please check whether all screws are tightened, to prevent parts from falling apart.

Tools:



Gloves



Ladder



Electric drill




Phillips screwdriver



Safety Helmet Hat



goggles




Note: Take care of sharp edges.

All panels are clearly marked and care should be taken to use the correct one. It is important that these instructions are followed step by step.

NO.	PART	Qty.	NO.	PART	Qty.	NO.	PART	Qty.
D1		1	D2		2	F14		14
D1L		1	D3L		1	F1		14
D1R		1	D3R		1			




tips: All F1 and F14 should be used together. The following steps are not explained.



Assemble the components in the positions shown in the diagram, then use F1 to secure the locations indicated in the diagram.




The installation space should be flat, and at least 3300x2000mm. The foundation is fixed on the ground in this space.






Note: Please wear gloves


NO.	PART	Qty.
F8		7



After installing the foundation, if the ground is soil, use F8 to secure the holes at the positions indicated in the diagram. If the ground is stone, expansion bolts must be used.











NO.	PART	Qty.
Q2		4
F1		12




Notice:

In this step, only the three holes in the middle of Q2 need to be installed and reserved on both sides. The reserved holes are shared with the following steps.








NO.	PART	Qty.	NO.	PART	Qty.
S1R		1	G2		4
S1L		1	F1		4
S3L		1	ZJT		1
S3R		1			




Notice:


G2 has been placed in the S1R and S1L positions prior to shipment. If it slides out, reinsert it following step A. Connect S1L and S1R via ZJT. After connecting S3L and S3R, secure them with F1.





NO.	PART	Qty.	NO.	PART	Qty.
S2		2	FJT		4
N1		1	F1		8







Assemble the components as shown in the diagram, then use F1 to secure the holes at the four corners. Next, position N1 in the corresponding location and align the holes.




NO.	PART	Qty.
F1		12











Notice:
 In this step, only the middle three holes need to be installed, and both sides need to be reserved.
 The reserved hole is shared with other steps.
 The walls are tiled on the outside and framed on the inside


NO.	PART	Qty.
Q1		8
Q3		5
F1		100
F11		16




Notice:
 As shown in the picture, assemble the wall tiles in turn, Q1\Q3, The top, middle and bottom of the wall tiles need to be screwed,
 The upper and lower ends are fixed with F1, and the middle is fixed with F11.








NO.	PART	Qty.
KL		1
KR		1
F1		8
F11		2








Notice:
 As shown in the picture, the steps of door frame and wall tile installation are the same.
 The upper, middle and lower parts of KR and KL need screws.
 The upper and lower ends are fixed with F1, and the middle is fixed with F11.




11

NO.	PART	Qty.
L1L		1
L1R		1
L2L		1
L2R		1
B1		4


NO.	PART	Qty.
F3		4
F1		10
B3R		1
B3L		1




Notice:
 Step A: B1 has holes on both sides,
 Large holes are used to connect 2 B1s, L2R and L2L, fixed with F3.
 Hole 2 B1s, connecting L2R and L2L, fixed with F1.
 Install B3L and B3R to the bottom and secure with F3.
 Step B: There are holes on both sides of B1. The large hole is secured from the outside using an F3.
 The holes are connected to L1R and L2R, L1L and L2L respectively, and are fixed with F1.






12


NO.	PART	Qty.
F1		22





Notice:
The assembled roof support parts are successively installed on the wall tiles with F1








NO.	PART	Qty.
Q4		9
F1		36



Notice:
Install Q4 in sequence, overlap between every 2 pieces, and each Q4 needs 3 rows of F1 fixed.





NO.	PART	Qty.	NO.	PART	Qty.
GB1		6	GB2		2
F1		20	J1		4















Notice:


Step A: Connect the 3 GB1 parts and fix them with F1.

Step B: Fix GB1, GB2, J1 parts with F1.





NO.	PART	Qty.	NO.	PART	Qty.	NO.	PART	Qty.	NO.	PART	Qty.
M2		4	M5L		1	M		4	F3		4
M3		4	M5R		1	GD		4	F4		12
M4		2	MB		2	F1		6			







NO.	PART	Qty.
F3		4
F1		6
F4		12



NO.	PART	Qty.
F1		8



Notice:

Use F1 to secure the installed door to the pulley

The adjustment of the door can be achieved by the three holes of the pulley being at different heights

